INSTRUCTION MANUAL



Multimatica


TABLE OF CONTENTS

Introducing the Multimatica	 03
The 24-Hour Display	 06
	 07
Changing the Straps	 08
Care Instructions	 09
Warranty	 10
Recycling and Disposal	 11
Contact	 12

Note: For illustration purposes, this manual uses images of the All Black Edition.


INTRODUCING THE MULTIMATICA

Elegance meets functionality – with the Multimatica, you'll always be on time!



SETTING THE TIME, DAY, AND DATE

It all starts with the right settings. You only need the crown for this!



To set the date:

- 1. Select the middle crown position (Pos. 2).
- 2. Turn the crown counterclockwise to the current date.

Please note: Do not set the date between 10 PM and 2 AM, as the day might not change correctly within the movement.



Setting the time and day of the week:

1. Pull out the crown (Pos. 3).

2. Turn the crown clockwise until you reach the current day of the week.

3. Continue turning the crown until you reach the correct time. Make sure to use the 24-hour display to determine AM or PM (see next page).

4. Everything set? Push the crown back in (Pos. 1).

THE 24-HOUR DISPLAY

A day has 24 hours. The Multimatica displays all of them.

The 24-hour display runs simultaneously with the main hour hand and shows the time from 0:00 to 24:00. When the hand is at the top, it is exactly midnight. When it is at the bottom, it is noon. This way, you can always keep track of the entire day.


TECHNICAL SPECIFICATIONS

We only use the best components for the Multimatica. These are:

Movement:	Multifunctional quartz movement
Caliber:	VH83A-M
Case material:	316L surgical steel
Case size:	36,25 x 30,75 x 7,60 mm
Glass:	Sapphire-hardened mineral glass
Water resistance:	3 bar

CHANGING THE STRAPS If you think your watch needs a new look, just change the strap!

To change the strap, push the small pin in the band inward (1). This shortens the bar and allows you to remove the band (2). To reattach it, pull the pin back and insert the bar into the holes in the case (3).



CARE INSTRUCTIONS

Your watch is quite easy to handle. However, there are a few things to keep in mind.

With a water resistance of 3 bar, it is well protected against water splashes, but it should not get too wet. If the battery runs out of power, simply take the watch to your trusted jeweler or watchmaker. The professional will replace the battery in no time! Our natural leather straps develop a fine patina over time, making them unique pieces! Dust and dirt can be removed with a slightly damp cloth. However, the straps should not get too wet. The stainless steel straps, on the other hand, handle moisture without any problems.

WARRANTY

We want to make you feel confident with your new watch

We offer you a 24-month warranty. If there is a material or manufacturing defect within this time, it is best to contact our customer service directly. We will take care of it quickly and without fuss, so we can all be happy again!

RECYCLING & DISPOSAL And if it ever comes to an end?

Used electrical devices and batteries must not be disposed of in household waste but must be taken to authorized collection points. This ensures environmentally friendly disposal and reuse of the components. Thank you!



Lilienthal Lifestyle GmbH Boxhagener Straße 78 10245 Berlin Germany

https://www.lilienthal.berlin/en https://www.lilienthal.berlin/uk https://lilienthal-berlin.com

լ

LILIENTHAL BERLIN